# PYTYM Proximity Transmitters and Seismic Vibration Transmitters

# **PVTVM's Transmitter Selection Guide**

Model Number	TR1101	TR3101 TR3102	TR4101 TR4102 TR4105	TR5102
	(t	(	Em (E	Trus (6
Acceleration (g's)	•			
Velocity (ips/sec, mm/sec)	•			
Displacement (mils, um)	•	•	•	
Vibration Measurements				
Radial Vibration		TR3101	TR4101	
Axial Position		TR3102	TR4102	
Phase Reference			TR4102 TR4105	•
Speed			TR4105	•
Case Vibration	•			
Sensor Interfaces				
Built in Accelerometer				
Proximity Probe (5mm, 8mm, and 11mm)		•	•	•
Accelerometer	•			
Velocity Transducer	•			
Available Outputs				
4-20mA Output	•	•	•	•
Buffered Output (3 meters)			•	
Buffered Output (300 meters)	•	•		•
Available Features				
Loop Powered (2- Wire) Transmitter			•	
3-Wire Transmitter	•	•		•
Hazardous Rating (CSA, ATEX)				
Explosion Proof, Class I, Class II, Div.1,				
Groups (A-G), EExdIICT4				
Hazardous Rating (CSA, ATEX)				
Intrinsically Safe, EExialICT4			•	
Hazardous Rating (CSA), non-incendive,				
Class I, Div.2, Groups (A-D, T4)			•	
Environmental Rating- NEMA 4 or IP65				
Low Pass and High Pass Filter				
Warranty- 5 years	•	•	•	•

• = Complete Offering





# **TR3101 Proximity 3-Wire Transmitter for Radial Shaft Vibration**

The TR3101 is a cost-effective solution for monitoring the radial vibration on balance of plant machines. The TR3101 combines the proximity probe driver and the signal conditioning circuit into one package. It works with the proximity probe and extension cable as a system.

#### **Features**

- ✓ Does not require proximity probe driver
- ✓ Buffered output/GAP will transmit signal up to 300 meters (1,000 feet)
- ✓ Compatible with other manufacturers' proximity probes (5mm, 8mm and 11mm)
- Aluminum cast (copper free) case with epoxy potting for better environmental protection and reliability
- √ Same size as a proximity probe driver









## **Specifications**

## **Electrical**

Power Supply:

20-30VDC

Frequency Response (±3dB):

2.0 - 3,000Hz

Probe and cable:

5 meter or 9 meter proximity probe and extension cable works with 5mm, 8mm, and 11mm probes

Proximity probe includes: TM0180, TM0105, TM0110, 3300, 7200, 990 series

Sensor Linear Range (reference with ANSI 4140 steel):

5mm, 8mm probe: 2.0 mm (80mil)

Approximately 0.25mm (10mil) to 2.25mm (90mil)

11mm probe: 4.0mm (160mil)

Approximately 0.4mm (15mil) to 4.4mm (175mil)

Overall Vibration:

4-20mA; Source

Buffered Output/ GAP:

Original vibration, un-filtered

Nominal: 2-18VDC

Impedance: 500Ω

Maximum cable distance: 300m (1,000ft) Sensitivity: 8.0mV/um (200mV/mil) nominal

Maximum Load:

 $500\Omega\,$ 

Isolation:

> 500Vrms; circuit to case

System OK:

System OK: output 4-20mA System Not OK: output < 3.0mA

### **Physical**

Height: 75mm (2.95") Weight: 0.5 kg (1.0 lb)



# Proximity Transmitters and Seismic Vibration Transmitters

#### **Environmental**

Temperature:

Operation:  $-40^{\circ}$ C to  $+70^{\circ}$ C Storage:  $-40^{\circ}$ C to  $+100^{\circ}$ C

Humidity:

90% non-condensing

#### **Order Information**

\* Factory default

Standard configuration:

#### TR3101-A00-E00-G00-S00

8mm probe:

#### TM0180-07-00-05-10-02

Extension cable:

TM0181-040-00

#### TR3101-AXX-EXX-GXX-SXX

#### **AXX: Full Scale**

A00\*: 0 - 200um (8.0mil) pk-pk A01: 0 - 500um (20mil) pk-pk A02: 0 - 100um (4.0mil) pk-pk A03: 0 - 250um (10mil) pk-pk

A04: 0 - 630um (25mil) pk-pk

A05: 0 - 125um (5.0mil) pk-pk

#### **EXX: Probe and Cable (not included)**

E00\*: TM0180, 8mm Probe, 5m Cable E01: TM0180, 8mm Probe, 9m Cable E02: 3300, 8mm Probe, 5m Cable E03: 3300, 8mm Probe, 9m Cable E04: 7200, 8mm Probe, 5m Cable

#### **EXX: Probe and Cable continued**

E05: 7200, 8mm Probe, 9m Cable

E06: TM0105, 5mm Probe, 5m Cable E07: TM0105, 5mm Probe, 9m Cable E08: TM0110, 11mm Probe, 5m Cable E09: TM0110, 11mm Probe, 9m Cable E10: 3300, 11mm Probe, 5m Cable E11: 3300, 11mm Probe, 9m Cable E12: 7200, 11mm Probe, 5m Cable

E13: 7200, 11mm Probe, 9m Cable

E14: 3309 Probe, 5m Cable E15: 3309 Probe, 7m Cable

E16: 3000, 190 Probe, 15 Feet Cable

E17: 3000, 190 Probe, 20 Feet Cable

E18: 3000, 300 Probe, 15 Feet Cable

E19: 3000, 300 Probe, 20 Feet Cable

E20: 7200, 5mm Probe, 5m Cable

E21: 7200, 5mm Probe, 9m Cable

#### **GXX: Mount**

G00\*: DIN rail mount G01: Plate mount SXX: Approval

S00\*: CE Mark

TR CU: № TC RU C-US.ΓБ05.B.00479

#### **TR3101 Accessories**

The TR3101 requires a proximity probe and extension cable to work as a system.

TM0180: 8mm probe TM0105: 5mm probe TM0110: 11mm probe TM0181: Extension cable

TM900A: Din Rail Mounted Power Supply

TM0200: 3-1/2 digit display unit

BNC-3: BNC adaptor for portable data collector



## **Field-Wiring Diagram**

